

{{ * SEE END OF FILE FOR TERMS OF USE

Name of Program	Author	Ver	Date
Spin_PASM_Style_Guide.spin	A. Hapgood	v1.00	03-DEC-2013
Provides the author with a template and style guide for Spin and PASM programming. Stack Space Required (Longs): Number of stack longs required by the object Use DD- MMM - YYYY date format. Use _v0.00 as a suffix for draft documents. Change suffix to v1.00 when content is complete. First Release: v1.00 Minor Revision: v1.01, v1.02, etc. Major Revision: v2.00, v3.00, etc. Minor release reset to zero * See OBJ section for required objects			

Changes	Ver	Date
Brief description of changes New stack space requirement if different Author Name	v#.##	DD- MMM - YYYY

123456789012345678901234567890123456789012345678901234567890123456789012345678901234567890
 80 columns wide

```

}}
'| Two blank lines at the end of each block to provide whitespace
'|
CON
'| ↑ Capitalize block designators

'| Pre-defined constants are lowercase and
'| preceded by an underscore if one-time settable
'| ↓ keep equals signs lined up with colons in OBJ section
'_clkmode      = xtall + pll16x
'_xinfreq      = 5_000_000
'| Predefined and one-time settable constants are bold faced automatically

'| ↓ User defined constants; UPPER_CASE and no preceding underscore
CONSTANT1     = 1
CONSTANT2     = 2
CONSTANT3     = 3
CLK_BURST_R   = $BF           'Clock - Burst Mode - Read

'| ↓ delimit long constant values with
'| ↓ underscores to arrange into logical groups
RAM_BURST_R   = %11_11111_1   'RAM - Burst Mode - Read ($FF)
RAM_BURST_W   = %11_11111_0   'RAM - Burst Mode - Write ($FE)
  
```

VAR

```
'↓ Two spaces between left margin and code
long Variables           'List purpose of variables
word Are                 'Short lines are commented like this and
byte CamelCase           'may span multiple lines
                          '↑ keep comments lined up
'Prefix variable names with a lowercase p when
'they are used as address pointers. pWolfNippleChips, etc.
```

OBJ

```
'↓ Object names are CamelCase
NameHere      : "objFileName"    'prefix with obj and CamelCase remainder
CamelCase     : "objCamelCase"
IsUsedForObj  : "objIsUsedForObjects"
              '↑ keep colons lined up with equals signs in CON section
```

```
PUB Init : ResultVar | temp, i
```

```
''Use single line documentation comment to briefly describe function
```

```
{{PUB and PRI function names are CamelCase
```

```
Result variable are CamelCase
```

```
Keep local variable names short and all lower case
```

```
Use Init for initialization actions, if needed
```

```
Use documentation comments when describing usage information
```

```
}}
```

```
''RETURNS: description of what is returned here
```

```
Code goes here
```

```
PUB Main
```

```
''Use main if this is a top object
```

```
Code goes here
```

```
'↓ Space before & after ↓
```

```
PUB Start( CogNum, pParam, pStack )'← parameters are CamelCase
```

```
''Use start and stop if this object launches a new cog and is not a top object
```

```
Case CogNum
```

```
'start specified cog
```

```
0..7 : coginit
```

```
'start next available cog
```

```
Other : cognew
```

```
'↑ spin functions are lowercase
```

PUB Stop

```
{{Use multi-line comments when there is more  
  than one line of documentation or comments  
}}
```

Code goes here

PUB More

```
''Some is good, more is better and too much is just right
```

More code happens here

PUB Examples

```
{{Use multi-line comments when describing theory}}
```

```
NewFreq := _xinfreq                                'Short line comments should all line up  
                                                'and can be more than one line
```

```
'Long lines get comments before them
```

```
NewFreq := _xinfreq * ( !PLLx #> || ( RCx == 0 ) ) + 12_000_000  
'  
      ↑ spaces between brackets and variables
```

```
'Unwieldy equations can utilize spacing to clarify logical groups
```

```
NewFreq := _xinfreq * ( PLLx #> || ( RCx == 0 ) ) + 12_000_000  
Variable := ObjName.Call( constant( pi / 2 + 3 ) )  
ObjName.Str( string( CONSTANT1, "String here!" ) )
```

PRI Internal

```
''Use PRIs when needed, especially if this is not a top level object
```

DoStuff := Here

CON

```
''Constants that will be used in assembly go here
```

DAT

```
''This section for spin only
```

```
'Indirectly addressed or program modified constants go here
```

```
LabelName      byte    "string", $AF, $ED
```

DAT

''Assembly code goes at the bottom

''Global labels are CamelCase

''Local labels are :lowercase

'↓ org statement lined up with instructions
org 0

' | instructions are lowercase

' | | destination operand

' | | | ↓ one space between destination and source

Pasm

mov pAddr, par 'get parameter pointer

mov pVar1, pAddr

add pAddr, #4 'prep for next long

mov pVar2, pAddr wz,wc

' | | | ↑ ↑ ↑ comma but no space
' | | | between effects fields

' | | effects fields are lowercase

' | | 2 spaces between source operand
' | | and effects field (lower case)

rdlong Var1, pVar1 wz

if_nz rdlong Var2, pVar2

'↑ conditions start in column 3 (leaves room for if_nc_and_nz)

'| conditions are predefined so are lower_case

'increment Var1 and Var2 by 1 in an endless loop

:loop call #IncVars 'inc Var1 and Var2 by 1

wrlong Var1, pVar1 'update variables

wrlong Var2, pVar2 'in hub RAM

jmp #:loop

IncVars add Var1, #1

add Var2, #1

IncVars_ret ret

```

'*****
'INITIALIZED VARIABLES
'*****
'Start PASM variable names on column 1; in line with PASM labels
'List pin variables first followed by other variables
'Initialized pin variables are UPPERCASE and should be short
'Other initialized variables are CamelCase
'Use 0-0 to indicate a variable is initialized elsewhere

CLK                long        0-0
CS                 long        |< 16                'pin assignment

PwmCycle           long        16_000                '5,000 cps @ 80 mHz
SampleHex          long        $F0F0F0F0            'hexadecimal

'32 bit binary assignment with delimiters
SampleBin          long        %0_00100_000_00000000_001110_000_001101

'*****
'UNINITIALIZED VARIABLES
'*****
'Uninitialized variables are CamelCase
'   single line comments can go here
pAddr              res          1                    ;or here
pVar1              res          1                    ;pointer vars are prefixed
pVar2              res          1                    ;with a lowercase p
Var1               res          1
Var2               res          1

'   fit          496
'   ↑            ↑ values line up with destination operand
'   | fit directive, res and long lined up with instructions

```

{{

THEORY OF OPERATION
Long descriptive information goes here, especially when describing theory. This section should be in the last block.

Valid Clock Modes	CLK Register Value
RCFAST	0_0_0_00_000
RCSLOW	0_0_0_00_001

This chart can be explained with comments over here

Tab Stops	Value
CON Block	2,19,39,79
VAR Block	2,8,39,79
OBJ Block	2,19,39,79
PUB/PRI Block	2,39,79
DAT Block	2,19,29,53,79

Settings from Edit - Preferences - Operation

TERMS OF USE: MIT License
<p>Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:</p> <p>The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.</p> <p>THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.</p>

1234567890123456789012345678901234567890123456789012345678901234567890
 80 columns wide

}}