

DOWNLOADING DRIVERS FOR THE FTDI USB-SERIAL CHIP  
(USED IN THE ACTIVE TAG READERS)

Should you wish to look for the latest drivers, get onto the FTDI web site using this link:  
[www.ftdichip.com/FTDrivers.htm](http://www.ftdichip.com/FTDrivers.htm)

You will see "Drivers" as one of the options on the left.

Select "VCP Drivers" (click on "Drivers" if this option is not shown).

Scroll down the page to the table headed "Currently Supported VCP Drivers".

The first line in the table is the Windows driver for Windows XP, Windows Server 2003, Windows Vista, Windows Server 2008, Windows 7 and Windows Server 2008 R2.

Under comments on the right of the Windows line click on "setup executable" and you should be in business.

Drivers for other operating systems are also available here.