



Assembly Instructions

1. Remove protective paper backing from all acrylic parts, warming them up with a hair dryer makes the paper come off much easier.
2. Attach the four rubber feet onto the bottom acrylic piece.
3. Assemble the 1/2" hex standoffs to the bottom piece using 5/16" screws.
4. Join the four edge braces to the side pieces, make sure they are fully seated.
5. Join the four side pieces to the bottom piece.
6. Place the P2 Eval Board on top of the edge braces.
7. Attach the top acrylic piece.
8. insert each 1/4" spacer between the top piece and the P2EVAL Board and fasten with a 3/4" machine screw.
9. Thread in the 3/16" nylon screw into the top piece and adjust so that it nearly touches the reset button.