101 PROJECTS FOR THE PPDB

BLINKING LED

Level: Easy Additional Requirements: None Spin file on CD: ppdb_project1.spin

Make the following connections:

(Propeller) P0 to (LED) 0

This is a great first project for anyone starting with the Propeller PPDB! Make the single wire connection, load the "ppdb_project1.spin" into Propeller Tool, and press [F10].

Explanation:

The command **DIRA[0]~~** sets Propeller P0 as an output device.

The commands **OUT[0]:=1 and OUT[0]:=0** turn the LED on and off.

The waitcnt(5_000_000+cnt) commands are timers. Try increasing or decreasing these numbers!