



p0	Status of NC push Button	p4	Not Used	p8	Stamp Data out to CLICK PLC	p12	Not Used
p1	Status of Left Selector	p5	Not Used	p9	CLICK Data into Stamp	p13	Not Used
p2	Status of Right Selector	p6	Data Received from CLICK PLC	p10	Not Used	p14	Not Used
p3	Status of NO Push Button	p7	Incrementing Stamp count	p11	Not Used	p15	Sending Data to CLICK PLC

Sci

**Stamp/EnT to CLICK
Comm Demo Setup**

Mar 4/10 EnT_CLICK