



**\* NOTES:**  
 Connector pinouts are shown from top (LED side) of board.  
 R2 is present only on Master.  
 J4 is present only on Master.  
 J3 is present only on Slave.  
 Jumper for J2 is included with Master, but not Slaves.

**7Seg-DB Schematic  
 (Master & Slave)  
 Version 1.3 (22 Jan 2007)  
 © 2007 Bueno Systems, Inc.**