



CABLE CONNECTION - LOGIC TABLE

RS485 OUT	RS485 IN	TERMINATE	MASTER
EMPTY	EMPTY	DISABLED	LOW
CONNECTED	CONNECTED	DISABLED	LOW
CONNECTED	EMPTY	ENABLED	HIGH
EMPTY	CONNECTED	ENABLED	LOW

AUTO TERMINATION - GALVANIC ISOLATED - MASTER/SLAVE DETECT 5V  
THIS SCHEMATIC IS NOT TESTED!!!

TITLE: RS485-INTERFACE BOARD REV-L

Document Number: REV:

Date: 30/03/09 Mon, 30 Mar 2009 5:16 PM 1/1