Propeller Eurocard Touchscreen 161



3/04/2012 11:47:02 PM f=0.51 C:\Program Files\EAGLE-5.0.0\projects\Propeller Eurocard Touchscreen 161\Propeller_Eurocard_Touchscreen_161.sch (Sheet: 1/1)