



Programming instruction for the BRIGHTSTAR remote

BR100L/BR100P/ BR100Q/BR100R/BR100Z

New Feature! Never Lose Code!

Programming your Remote

1. Manually turn on the TV.
2. Press and hold the SET-UP key until the LED blinks and remains on, then release the button.
3. Find your 3-digit code from the code table and enter it. After the code is entered the indicator light will turn off and you are done.

NOTE: If the LED blinked rapidly when you entered the code you may have entered an invalid code; recheck the code list and try again. Also if volume and channel functions do not work then you do not have an exact code match and please try another code.

4. Enter your code here for reference

To return to Factory Setting (Pre-programmed for a specific brand)

1. Press SETUP and hold until LED stays on.
2. Press CC

Programming your Remote using code search.

If the code for your TV is not listed or you cannot get the TV to respond try the following:

1. Turn on the TV.
2. Press and hold the SET-UP key until the LED blinks and remains on, then release the button.
3. Press the channel [CH+] up button slowly over and over again (60 or more times) **until the channel changes**. The LED will blink and then stay lit. If you bypass the code just press CH- key to go backward through the library until the TV changes channels. Pressing CH+ changes direction to forward again.
4. Now press MUTE to lock in the code.

Code identification

1. Turn on the TV.
2. Press and hold the SET-UP key until the LED blinks and remains on.
3. Press the SET-UP key again and release.
4. Now press each number key slowly from 0 to 9 and when the light blinks that is the first digit of your code. To find the next digit repeat step 4 again and when the light blinks you have found the second digit. Repeat one more time to get the third digit.

Sleep mode

This remote has an internal timer so even if your TV does not have sleep feature, it will work.

1. Turn on the TV.
2. Press and hold the sleep key until the light blinks and stays on. Then release the key.
3. Choose the time between 01 and 99 minutes (two-digit number). The LED will blink and remain off. The timer is now set.
4. The remote must be left pointing toward the TV so it can send the signal to shut the TV when the time elapses. (Obviously, the signal cannot be blocked by anything or it will not work.)
5. To deactivate sleep mode either press the power key or press and hold the sleep key