error: List index out of bounds (-1) SX-Key 3.10

Description of the error found in SX-Key Editor 3.10. See the forum thread: http://forums.parallax.com/forums/default.aspx?f=7&m=77602&r=x.


Step to reproduce the problem, after the system was clean from any parallax software (registry and hard drive):

For all these step the SX-Key Rev. F module was never connected to any serial port.

- 1. Install "SX-KeyEditor3 1.exe"
 - HKEY CURRENT USER\Software\ParallaxInc\ is not created at this step.
- 2. Start program "SX-Key v3.1" for the first time.
 - 1. First time running dialog is show.




- 1. Click OK button.
- 2. Configuration dialog is show.



1. Change some option (i.e. Tab size from 8 to 2) but no Serial Port is selected.

- 2. Click OK button.
- 3. Error!



- 1. Click OK button
- 4. State of the registry: "afterconfigwitherror.reg"
- 5. Software disclaimer dialog is show (this dialog is not show again after the first time).
 - 1. Click OK button.
- 6. The editor is now open and can be used for editing.
 - 1. The option changed in the configuration window is not saved (i.e. Tab size is still 8 and not 2).
 - 2. Close the software.
- 3. State of the registry: "afterclosingwitherror.reg"
- 4. Start program "SX-Key v3.1" for the second time.
 - 1. First time running dialog is show.
 - 1. Click OK button.
 - 2. Config dialog is show.
 - 1. Change some option (i.e. Tab size from 8 to 2) and set the serial com port to com 3 (in my case).
 - 2. Click OK button.
 - 3. No error
 - 3. State of the registry: "afterconfigwithouterror.reg"
 - 4. The editor is now open and can be used for editing.
 - 1. The option changed in the configuration window is saved (i.e. Tab size is now 2).

- 2. Close the software.
- 5. State of the registry: "afterclosing withouterror.reg"
- 5. Start program "SX-Key v3.1" for the third time.
 - 1. Everything is correct.