

I/F基板		マイコン側	
1	DB0	1	P10
2	DB1	2	P11
3	DB2	3	P12
4	DB3	4	P13
5	GND	20	
6	VCC	40	
	/CS	10	P30
8	RS	13	P33
9	WR	14	P34
10	RD		
11	IM0		
12	XL		
13	YU		
14	XR		
15	YD		
16	LEDA	40	
17	LEDK1	20	
18	LEDK2	20	
19	LEDK3	20	
20	LEDK4	20	
21	IM3	20	
22	DB4	5	P14
23	DB10	21	P20
24	DB11	22	P21
25	DB12	23	P22
26	DB13	24	P23
27	DB14	25	P24
28	DB15	26	P25
29	DB16	27	P26
30	DB17	28	P27
31	RESET	11	P31
32	VCC	40	
33	VCC	40	
34	GND	20	
35	DB5	6	P15
36	DB6	7	P16
37	DB7	8	P17